



Assembly Instructions for RockBoard® Slot Cover for RockBoard® Pedalboards English

Thank you for choosing the **RockBoard®** Slot Cover. It provides an elegant solution for unused slots on your pedalboard, giving it a professional and tidy appearance by covering empty slots. On the inside of the **RockBoard®** Slot Cover you will find drilling templates for common connectors such as XLR, 6.3 mm 1/4" jacks and Speaker Twist. Made of high quality materials, the Slot Cover guarantees durability and resilience even in demanding stage situations. Installation is easy and requires no special tools.

Installation



Remove the white rubber frame from the edges of your pedalboard slot.



Turn the **RockBoard®** Pedalboard around.



Insert the Slot Cover into the slot on your **RockBoard®** Pedalboard from the inside.



Insert the supplied screws and hand-tighten them to secure the Slot Cover.

Note: The manufacturer reserves the right to change the technical data without prior notice.